

## **Plastic Purple Martin House Assembly Instructions**

**(located on the back side of the carton)**

**Note: Must be assembled unto the pole.....**

1. Locate 2 clamp brackets and hardware (item number 1&2). Assemble the 2 clamp brackets approximately 24" from the end of a 1 ¼" OD diameter pole, temporarily tighten with an equal amount of space between the clamp brackets on each side of the pole. Figure 1.
2. Place a floor section (grid pattern downward) on the pole. Slide floor section downward; fit clamp assembly into socket and underside floor slots. Figure 2.
3. Place a long divider (item number 4) on the pole, snap locks downward. Slide it down the pole into the slot located in the center of the upper side of the floor sections. Figure 3.
4. Place 2 short dividers (item number 5), tabs upward, into the slots in the upper side of the floor and long dividers. Figure 4.
5. Place 2 short exterior walls, (item number 7), rounded ends of windows pointing upward and snap locks downward, into upper side of floor, allowing snap locks to lock. Figure 5.
6. Place the second floor (item number 3) on the pole, slide down and align the slots in the floor section underside with the tabs on the tops of the end walls and divider sections. Allow the floor to rest on the tabs. Figure 6.
7. Repeat steps 3-5 for second story compartment assembly.
8. Place the roof (item number 8) over the pole allowing the top of the pole to protrude through the chimney. Slide the roof down unto the second story dividers and end walls. Align and insert the tabs on the tops of the end walls and dividers into the round sockets in the roof section underside. Figure 7.
9. Set up the long exterior walls (item number 6) by inserting the pins on the top ends, into the slots in the top ends of the short end walls. The long exterior wall hinges on the top and snaps in place on the upper side of the floor on the bottom. Note: The pins hinge the long exterior walls so that they can be lifted upward and outward allowing cleaning without disassembling the house. Figure 8.
10. Check all tabs for proper alignment. Attach two clamp brackets (item number 1) 1/8" below the end of the pole, tighten the clamp equally on each side. Figure 9.
11. Loosen the bottom pole clamp, ¼" space must be between the two clamp brackets on each side of the pole. Push the clamp assembly up against the underside of the bottom floor and into the slots created by the grid pattern. Between the two clamp brackets there will be two grid bars with a small space between them. Push the clamp assembly and house upward on the pole aligning the top clamp assembly with the chimney. The house should be tight between the clamps. Tighten the clamp equally on each side. Figures 10 & 11.
12. Snap chimney cap (item number 9) into place on top of chimney. Figure 12.